

How to clean SUPERAIR-III bus air purifier

Video link: <https://youtu.be/O92x9vxWsA0>

Our bus purifier itself gets dirty during fulfilling its duty in the bus after some time due to external environment, dust may accumulate on the device, and it would not only affect purification performance, but also give rise to static arc and abnormal sound. So we need to clean and maintain our Superair-III air purifier.

Please follow me to clean it!

1. Turn off bus A/C, unplug the harness plug-in.
2. Take out the purifier by loosening the four screws.
3. Use a vacuum clean to clean the surface or remove the dirt by a clean rag.
4. Power on the purifier and see if works well, and install it back to where it is.
5. Turn on the bus A/C, take a look if the ultraviolet light is on, if it is, it means our purifier is working well.

Notice:

1. It is strictly prohibited to wash or clean the device by water or volatile liquid.
2. Pay attention to the sharp points when you are cleaning with a rag.
3. We suggest you to clean the purifier once every 4-6 months. If external air quality is fine or good, you can clean it every half year. But in case the air quality is bad, you should clean it not more than 3 months.
4. Tools needed: screwdriver, torque wrench (torque < 8N), vacuum cleaner or rag.

Feel free to contact us when you need assistance.